



MAILING

PO BOX 677
ROGERSVILLE, MO, 65742

SHIPPING

11 WHITE OAK ROAD,
ROGERSVILLE, MO, 65742

Scan QR Code for
More Information



www.p1mfg.com

(417) 753-5174



HEAD STUD KIT

KIT NUMBER

K003-H14H

APPLICATION

CHEVROLET LS HEAD STUD KIT,
DART IRON LS NEXT, 7/16"
STUDS, 23 STUDS PER HEAD,
12PT NUTS, H260 SERIES, PLAIN
FINISH

FASTENER INSTALLATION

1. Inspect kit contents for damage and confirm quantities.
2. Thoroughly clean all debris from engine block holes and threads.
3. Ensure all mating deck surfaces and fastener bearing surfaces are flat, free of debris and dry of any cleaning related products.
4. Inspect all deck gaskets for damage, fitment, & suitability.
5. Remove washers from packaging and remove rust preventative coating from all faces of washers, place on clean rag (petroleum-based solvent is recommended).
6. Remove remaining fasteners and place on clean shop rag, clean threads as required, (do not unnecessarily remove rust preventative).
7. Without lube, washers, gaskets or heads, thread studs into their intended holes by hand only until stud bottoms or thread run-out occurs (do not use tools). Achieving smooth installation without tools is necessary. Remove fasteners and clean or repair threads if needed.
8. Remove fasteners from their holes and apply TORQUEPOINT assembly lube to entire length of block end threads of the fastener using included brush. Work lube into threads all the way around the threaded sections so lube is nearly flush with outer diameter of thread face.
9. Install studs into block by hand or using hex key with light force only.
10. Thoroughly clean any visible fastener lube from mating surfaces and fit gasket and head on block and install washers onto studs. The washers should be dry during installation. DO NOT USE LUBE ON THE WASHERS.
11. Apply TORQUEPOINT assembly lube to entire length of nut end threads of the fastener using included brush. Work lube into threads all the way around the threaded sections so lube is nearly flush with outer diameter of thread face. Lube should be evenly distributed and not excessive.
12. Apply TORQUEPOINT lube to each nut's bearing surface only. Do not use lube on the washers. Install nuts with washers, hand tight. The washer should not rotate during torque procedure.

KIT CONTENTS

SH4S (10)	STUD - MJ8x1.25 x 5/16-24 UNJF x 2.73 [69.3] OAL, S220, BLACK OXIDE
SA3S (8)	STUD - MJ8x1.25 x 5/16-24 UNJF x 2.52 [64.0] OAL, S220, BLACK OXIDE
SS4H (16)	STUD - 7/16-14 UNJC x 7/16-20 UNJF x 3.46 [87.9] OAL, H260, PLAIN
SS5H (4)	STUD - 7/16-14 UNJC x 7/16-20 UNJF x 3.65 [92.7] OAL, H260, PLAIN
SS6S (8)	STUD - 3/8-16 UNJC x 3/8-24 UNJF x 2.25 [57.2] OAL, S220, BLACK OXIDE
WC7T (8)	WASHER - FLAT - M9-3/8 NOMINAL x .640 O.D. x .12 THK, HARDENED & GROUND, BLACK OXIDE
WA4T (20)	WASHER - FLAT - M11-7/16 NOMINAL x .850 O.D. x .12 THK, HARDENED & GROUND, BLACK OXIDE
WB2T (18)	WASHER - FLAT - M8-5/16 NOMINAL x .550 O.D. x .12 THK, HARDENED & GROUND, BLACK OXIDE
NB1F (8)	NUT -12PT FLANGE, 3/8-24 UNJF-3B, 1/2 WRENCH, .700 FL Ø, BLACK OXIDE
NA5F (18)	NUT -12PT FLANGE, 5/16-24 UNJF-3B, 3/8 WRENCH, .520 FL Ø, BLACK OXIDE
NB5F (20)	NUT -12PT FLANGE, 7/16-20 UNJF-3B, 9/16 WRENCH, .823 FL Ø, BLACK OXIDE
TP0S (1)	TORQUEPOINT FASTENER ASSEMBLY LUBE, 0.5oz TUBE
LBBR (1)	LUBE APPLICATION BRUSH

TORQUE RECOMMENDATION

Follow applicable OEM and/or aftermarket manufacturers suggested torque sequence & number of tightening steps.

Point One fasteners, paired with TORQUEPOINT fastener assembly lube, can sustain the following nominal torques and clamp loads while remaining below their minimum proof load rating.

*****DO NOT EXCEED THESE TORQUE INPUT VALUES*****

*****THESE VALUES WILL NOT BE APPLICABLE WHEN USING OTHER LUBRICANTS*****

SH4S, SA3S

Torque: **33 ft-lbs**
Typical Clamp Load: **7300 lbs-force**

SS4H, SS5H

Torque: **95 ft-lbs**
Typical Clamp Load: **15500 lbs-force**

SS6S

Torque: **50 ft-lbs**
Typical Clamp Load: **10500 lbs-force**

Note: The number of aftermarket replacement parts and OEM combinations of components is numerous. Use caution as the clamp loads listed above may damage your assembly - use lower installation torques such as those provided by the manufacturer of your components if applicable.